
USER GUIDE (WINDOWS)

PanaCast® 2 Camera: Cisco WebEx®




(I) Access Call Settings

 To change your call settings select the "Gear" icon directly above your video display.




(2) Select PanaCast Camera

 Select "PanaCast" as your camera in the drop down menu.




(3) Change Webcam Settings

 To change your webcam settings, click "Advanced Options" beneath your video preview to edit more advanced settings.



(4) Tracking Call Stats

 To get Call Info navigate to "Meeting" and click on "Audio & Video Statistics..."



Digital Zoom with PanaCast ePTZ

PanaCast allows the host user to digitally pan, tilt and zoom in their video stream using the PanaCast ePTZ app. To find out more, please click here for instructions.



Altia Systems, Inc. | 10020 North De Anza Blvd., Suite 200 | Cupertino, CA 95014 | Office: 1(408) 996 9710

Contact us: support@altiasystems.com