


(1) Make a Zoom Call

- This is the screen that will appear when you want to make a call in "Zoom."



(2) Access Call Settings

- To change your call settings, click on the "Gear" icon right below your video feed with "Settings" next to it.




(3) Select PanaCast Camera

- Click on the "Video" tab and select "PanaCast" from drop down menu.



(4) Track Call Stats

- To track call info and stats simply click on the "Statistics" tab in the taskbar and then select "Technical Call Info."



Digital Zoom with PanaCast ePTZ

PanaCast allows the host user to digitally pan, tilt and zoom in their video stream using the PanaCast ePTZ app. To find out more, please click [here](#) for instructions.



Altia Systems, Inc. | 10020 North De Anza Blvd., Suite 200 |
Cupertino, CA 95014 | Office: 1(408) 996 9710

Contact us: support@altiasystems.com